

# MAINTENANCE

---

Maintenance is essential to keep your caravan in a safe and usable condition. Caravans are no different to any other motor vehicle and require servicing at regular intervals which may vary according to use and the environment in which it is used. The service schedule outlines the service intervals for safe travelling and your owner obligations under our warranty policy. Servicing should always be carried out by a competent person with relevant experience.

## WARNING:

- NEVER WORK BENEATH THE CARAVAN WHILE SUSPENDED ON A JACK. ALWAYS USE “JACK STANDS” WITH AN ADEQUATE SWL (SAFE WORKING LOAD).
- ALWAYS USE DEDICATED JACKING POINTS
- 240V APPLIANCES AND WIRING MUST ONLY BE SERVICED AND REPAIRED BY A QUALIFIED TRADESPERSON.
- GAS PLUMBING AND APPLIANCES MUST ONLY BE SERVICED AND REPAIRED BY A QUALIFIED GAS FITTER



## Service Definitions

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

\*Wheel alignment - Inspect daily during the 1000km running in period. Adjust as required if change in alignment position is noticed. Also monitor daily in severe operating environments

\*Suspension bushes - Apply grease daily in severe operating environments including water crossing to avoid premature wear due to contamination

\*240V Power system - Ensure is inspected and tested annually by a suitably qualified tradesperson. General servicing does not include 240V system inspections

\*LPG system - Ensure system is inspected and tested annually by a suitably qualified trade person. General servicing does not include LPG system testing

\*Panel and paint - To ensure your caravan is well protected, apply carnauba wax initially and annually to external painted walls and decals. Do not apply to Line-X coated surfaces

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	Daily In Use	CHECKED	3 Months/ 1,000KM		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I		I/A	I/A	
HITCH	I		I/A/L	I/A/L	
JOCKEY WHEEL	I		I/A	I/A	
STABILISER LEGS	I		I	I	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		A	A	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		A/T	I/A/T	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		I/L	I/L	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I	I	
ELECTRIC STEP	I		I	I/L	
ELECTRIC AWNING	I		I/A	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	T		I/T/A	I/T/A	
*240V POWER SYSTEM	T		T	T	
*LPG SYSTEM	I		I	I	
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I		I	I/A	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I		I	I/A	
WINDOW BLINDS AND HANDLES	I		I	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I		I/A	I/A	
VENT FILTERS	I		I	I	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	2500Km Severe use	CHECKED	6 Months/ 5,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/A	I/C/L	
STABILISER LEGS	I/A		I/A	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		I/A	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		A/T	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		I/L	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I	I/C	
ELECTRIC STEP	I/C/L		I/L	I/C/L	
ELECTRIC AWNING	I		I	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		T	T	
*LPG SYSTEM	I		I	I	
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	7500Km Severe use	CHECKED	12 Months/ 10,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A/L	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/C/L	I/C/L	
STABILISER LEGS	I/A		RCL	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		RCL	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		RCL	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		RCL	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I/C	I/C	
ELECTRIC STEP	I/C/L		I/C/L	I/C/L	
ELECTRIC AWNING	I		I/A	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		Contractor outsourcing - additional fee		
*LPG SYSTEM	I		Contractor outsourcing - additional fee		
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/C/L	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	10,000Km Severe use	CHECKED	18 Months/ 15,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/A	I/C/L	
STABILISER LEGS	I/A		I/A	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		I/A	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		A/T	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		I/L	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I	I/C	
ELECTRIC STEP	I/C/L		I/L	I/C/L	
ELECTRIC AWNING	I		I	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		T	T	
*LPG SYSTEM	I		I	I	
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	15,000Km Severe use	CHECKED	24 Months/ 20,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A/L	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/C/L	I/C/L	
STABILISER LEGS	I/A		RCL	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		RCL	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		RCL	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		RCL	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I/C	I/C	
ELECTRIC STEP	I/C/L		I/C/L	I/C/L	
ELECTRIC AWNING	I		I/A	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		Contractor outsourcing - additional fee		
*LPG SYSTEM	I		Contractor outsourcing - additional fee		
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/C/L	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	17,500Km Severe use	CHECKED	30 Months/ 25,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/A	I/C/L	
STABILISER LEGS	I/A		I/A	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		I/A	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		A/T	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		I/L	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I	I/C	
ELECTRIC STEP	I/C/L		I/L	I/C/L	
ELECTRIC AWNING	I		I	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		T	T	
*LPG SYSTEM	I		I	I	
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	22,500Km Severe use	CHECKED	36 Months/ 30,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A/L	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/C/L	I/C/L	
STABILISER LEGS	I/A		RCL	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		RCL	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		RCL	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		RCL	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I/C	I/C	
ELECTRIC STEP	I/C/L		I/C/L	I/C/L	
ELECTRIC AWNING	I		I/A	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		Contractor outsourcing - additional fee		
*LPG SYSTEM	I		Contractor outsourcing - additional fee		
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/C/L	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	



# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	25,000Km Severe use	CHECKED	42 Months/ 35,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/A	I/C/L	
STABILISER LEGS	I/A		I/A	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		I/A	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		A/T	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		I/L	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I	I/C	
ELECTRIC STEP	I/C/L		I/L	I/C/L	
ELECTRIC AWNING	I		I	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		T	T	
*LPG SYSTEM	I		I	I	
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	30,000Km Severe use	CHECKED	48 Months/ 40,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A/L	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/C/L	I/C/L	
STABILISER LEGS	I/A		RCL	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		RCL	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		RCL	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		RCL	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I/C	I/C	
ELECTRIC STEP	I/C/L		I/C/L	I/C/L	
ELECTRIC AWNING	I		I/A	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		Contractor outsourcing - additional fee		
*LPG SYSTEM	I		Contractor outsourcing - additional fee		
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/C/L	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	32,500Km Severe use	CHECKED	54 Months/ 45,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/A	I/C/L	
STABILISER LEGS	I/A		I/A	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		I/A	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		A/T	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		I/L	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I	I/C	
ELECTRIC STEP	I/C/L		I/L	I/C/L	
ELECTRIC AWNING	I		I	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		T	T	
*LPG SYSTEM	I		I	I	
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	

# MAINTENANCE SCHEDULE

Service stamp

DATE:

A=Adjust C= Clean I=Inspect T=Test R=Replace RCL=Remove/Clean/Lubricate

ITEM/COMPONENT	37,500Km Severe use	CHECKED	60 Months/ 50,000Km		CHECKED
			ONROAD	OFFROAD	
HOUSE BATTERY CONDITION	I		T	T	
BRAKE AWAY BATTERY CONDITION	I/T		I/T	I/T	
HANDBRAKE CABLE	I/L		I/A/L	I/A/L	
HITCH	I/A/L		I/A/L	I/A/L	
JOCKEY WHEEL	I/C/L		I/C/L	I/C/L	
STABILISER LEGS	I/A		RCL	RCL	
*WHEEL NUTS	I/A		I/A	I/A	
WHEEL BEARINGS	I		RCL	RCL	
TYRE PRESSURE	I		I/A	I/A	
BRAKE LININGS	T		RCL	RCL	
*WHEEL ALIGNMENT	I		I/A	I/A	
*SUSPENSION BUSHES	I		RCL	RCL	
SUSPENSION TORQUE	A		A	A	
SHOCK ABSORBERS	I		I/A	I/A	
CHASSIS LUBE AND GREASE NIPPLES	I		I/L	I/L	
STRUCTURAL FIXINGS	I		I/A	I/A	
GAS STRUTS	I		I/C	I/C	
ELECTRIC STEP	I/C/L		I/C/L	I/C/L	
ELECTRIC AWNING	I		I/A	I/A	
SIGNALLING LIGHTS	I/T		I/T	I/T	
12V POWER SYSTEM	I/T/A		I/T/A	I/T/A	
*240V POWER SYSTEM	T		Contractor outsourcing - additional fee		
*LPG SYSTEM	I		Contractor outsourcing - additional fee		
TRUMA WATER HEATER	Refer to appliance manufacturers maintenance instructions for servicing and storage requirements				
PLUMBING PRESSURE SYSTEM	I/T		I/T	I/T	
PLUMBING DRAINAGE SYSTEM	I		I	I/T	
WATER TANKS	I		I	I	
EXTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/C/L	I/C/L	
INTERNAL LOCKS/HINGES/SLIDE RAILS	I/A		I/A	I/A	
WINDOW BLINDS AND HANDLES	I/A		I/A	I/A	
EXTERNAL SEALS AND GROMMETS	I		I	I	
INTERNAL SCREWED FIXINGS	I/A		I/A	I/A	
VENT FILTERS	I/C		I	I/C	
SMOKE ALARM	T		T	T	
FIRE EXTINGUISHER	I		I	I	
*PANEL AND PAINT	I		I	I	
WATER + DUST INGRESS	I		I	I	



# EZYTRAIL

## VICTORIA

### Kilsyth Branch Office

5 Southfork Drive  
Kilsyth, VIC 3137  
P: 03 9728 3147



### Campbellfield Branch Office

1924 Sydney Road  
Campbellfield, VIC 3061  
P: 03 9357 9603



### Geelong Branch Office

2 Sharon Court  
North Geelong, VIC 3215  
P: 03 5260 2900



## NEW SOUTH WALES

### Lansvale Branch Office

178-180 Hume Highway  
Lansvale, NSW 2166  
P: 02 9754 2176



### Penrith Branch Office

22 Lemko Place  
Penrith, NSW 2750  
P: 02 4701 5782



### Newcastle Branch Office

5 Archibald Place  
Heatherbrae, NSW 2324  
P: 02 4987 7731



## QUEENSLAND

### Brisbane Branch Office

1699 Ipswich Road  
Rocklea, QLD 4106  
P: 07 3157 8240



### Sunshine Coast Branch Office

55-57 Lear Jet Drive  
Caboolture, QLD 4510  
P: 07 5348 0240



### Townsville Branch Office

64 Pilkington Street  
Garbutt, QLD 4814  
P: 07 4725 3806



## SOUTH AUSTRALIA

### Adelaide Office Branch

283 North East Road  
Hampstead Gardens, SA 5086  
P: 08 8261 5865



## WESTERN AUSTRALIA

(PMX STORES)

### South Perth Branch Office

1/196 Bannister Road  
Canning Vale, WA 6155  
P: 08 9455 1454



### North Perth Branch Office

1/33 Dellamarta Road  
Wangara, WA 6065  
P: 08 9309 4000

